



# Ultrawave

Precision ultrasonic cleaning equipment

Ultrawave Ltd  
Eastgate Business Park  
Wentloog Avenue  
Cardiff CF3 2EY  
United Kingdom

Telephone +44 (0) 845 330 4236  
Fax +44 (0) 845 330 4231  
Email [admin@ultrawave.co.uk](mailto:admin@ultrawave.co.uk)  
Web [www.ultrawave.co.uk](http://www.ultrawave.co.uk)

## Ultraclean CS Technical Data Sheet

### Description:

Ultraclean CS is an alkaline detergent for use in ultrasonic baths.

- Aqueous based product
- Grease removal in industrial applications
- Reduces surface tension, enhances ultrasonic cleaning performance
- Contains de-foaming agent

### Applications

Used for cleaning components in manufacturing and processing industries, Ultraclean CS can be used to remove moderate grease and other contaminants from plastics, glass, metals and other materials. (Not suitable for processing aluminium or other soft metals. Instead, please use Ultraclean SA)

### Directions for Use

Add 20-50ml of Ultraclean CS per 1 Litre of water in the ultrasonic cleaner. Do not mix with other solutions.

The required dosage will depend on your cleaning application and the level of contamination. Items should be rinsed with water and dried immediately after processing.

### Technical Data

These figures are typical and should not be interpreted as specifications, refer to MSDS for details.

Characteristic	Value/Description
Appearance	Light brown liquid
Odour	Mild
pH (@ 1%)	11 – 12 @1%
Relative density	1.05

Available in:

- 6x1L box (Part no. F5000801)
- 25 Litre Drum (Part no. F5000701)



### Disposal

When used at a dosage of less than 5% by volume, Ultraclean CS is not hazardous to aquatic organisms and may be safely disposed of down the drain. Refer to regional or national regulations.

### Storage

12 months when stored in a cool, dark environment.

Registered in the UK No. 2558071  
VAT Registration No. GB 827 1111 60  
A list of directors is available on request  
from the registered office